

# SHARP®

## Quick Start Guide

MODEL

**XL-HF202PH(S)**  
**XL-HF202PH(BK)**  
**XL-HF302PH(T)**










**HI FI COMPONENT SYSTEM**

If you require any advice or assistance regarding your Sharp product, please visit our web-site [www.sharp.co.uk/support](http://www.sharp.co.uk/support)

Customers without internet access may telephone 0845 880 0512 during office hours (or (01) 676 0648 if telephoning from Ireland).

This Quick Start Guide will help you to correctly install and operate your system.


## 1 Accessories

								
Remote control x 1 RRMCGA334AWZZ	"AA" size battery (UM/SUM-3, R6, HP-7 or similar) x 1	Stand for iPad x 1	NFC tag x 2	Speaker wires x 2 (for XL-HF202PH(S) / XL-HF202PH(BK))	Speaker wires x 2 (for XL-HF302PH(T))	FM aerial x 1	Velcro tape (hook type) x 2	Velcro tape (loop type) x 3


## 2 Remote control battery installation

Use "AA" size batteries (UM/SUM-3, R6, HP-7 or similar).

- 1 Open the battery cover.
- 2 Insert the batteries as shown.
- 3 Close the cover.




## 3 System connections



TINSEA452AWZZ

## 4 Turn on your system

Press the ON/STAND-BY button to turn the power on.



## 5 Bluetooth one touch connection via NFC

This audio system supports NFC-enabled device with Android 4.1, Jelly Bean and higher.

### ■ NFC tag set up


The NFC tags can be placed anywhere convenient to you. The velcro tapes supplied will help to secure the tags onto the desired location.

#### Caution :


- Make sure that the NFC tag is placed on a flat and level surface.
- If you choose not to use the velcro tape, do not place the NFC tag near metal surface to avoid connection interference during tagging.

Keep all small parts away from children as they may be accidentally swallowed.

- 1 Peel the separator off the velcro tape (loop type) and stick it on a desired surface.



- 2 Peel the separator off the velcro tape (hook type) and stick it to the rear of the NFC tag. Then place the tag onto the desired location.



### ■ NFC connection for audio playback


#### Check that :

- Your device (smartphone / tablet) has an NFC function.
- NFC function on your device is turned on.
- Screen lock function of the device is off.
- This unit is not in Eco mode.

- 1 Touch your device to the supplied NFC tag.

- 2 A pop-up window asking whether to proceed with the Bluetooth connection appears on the device. Select <YES>.

- The 'connected' message appears when the connection is complete.



- 3 Playback will start automatically. Otherwise, press play (on remote control or source device).

- Sound will be heard from the speakers of this unit via audio streaming.
- Your device and NFC tag must be within 10 meters from the unit.

#### Bluetooth operation buttons (remote control only)


	Press the button to play or pause.
	Press the button to skip up.
	Press and hold to fast forward.
	Press the button to skip down.
	Press and hold to fast reverse.

#### Note :


- To listen to audio via Bluetooth connectivity without NFC tag - refer "Pairing with other Bluetooth source devices" on page 8 of the operation manual.
- To disconnect, simply touch your device to the tag again.

## 6 Listening on Android™ devices

- 1 Insert the connector to the device.



- 2 Connect the device to the main unit via USB connector.



### ■ Android device playback

- 1 Press the ON/STAND-BY button to turn the power on.
- 2 Press the USB button (remote control) or FUNCTION button repeatedly (main unit) to select USB function.
- 3 Connect the device (Smartphone/Tablet) to the unit.
- 4 Press the play button (on main unit, remote control or device).

### ■ To disconnect the Android device

- 1 Quit the application (apps).
- 2 Disconnect the device from the USB terminal.